



- To Print Template
- 1) Open in PDF reader
 - 2) Select Print
 - 3) Select 'Actual Size'
 - 4) Print

All dimensions in inches

Two Post



Three Post



Four Post

